

# OWNER'S GUIDE

MODEL NOS. 141-760 10 H.P.  
141-860 12 H.P. — 141-960 14 H.P.

## GARDEN TRACTOR

*Snow Blade 191-763*

*Deck 192-761 - N/A*



### WARRANTY

For one year from date of purchase, MTD Products Inc. will replace for the original purchaser, free of charge, F.O.B. factory or authorized service firm, any part or parts found to be defective in material or workmanship. All transportation charges on parts submitted for replacement under this warranty must be paid by the purchaser. This warranty does not include replacement of parts which become inoperative through misuse, excessive use, accident, neglect, improper maintenance or alterations by unauthorized persons. This warranty does not include the engine, motor, battery, battery charger or any component parts thereof. For service on these units refer to the applicable manufacturer's warranty.

The above warranty will apply only to the original owner and will be effective only if the warranty card has been properly processed. It will not apply where the unit has been used commercially.

Warranty service is available through your local authorized service dealer or distributor. UNDER NO CIRCUMSTANCES WILL THE RETURN OF A COMPLETE UNIT BE ACCEPTED BY THE FACTORY UNLESS PRIOR WRITTEN PERMISSION HAS BEEN EXTENDED.

MTD PRODUCTS INC. • 5389 WEST 130TH ST. • P.O. BOX 2471 • CLEVELAND, OHIO 44111

# BE A PRO! KNOW YOUR MACHINE — HOW TO CONTROL IT SMOOTHLY, AND HOW TO STOP IT QUICKLY! AND — READ THE OWNERS MANUAL

## SAFETY TIPS FOR GARDEN TRACTORS AND ATTACHMENTS

Improper use of riding lawn mowers, garden tractors and attachments on the part of the operator can result in injury. To reduce this possibility, give complete and undivided attention to the job at hand.

1. Know the controls and how to stop quickly — READ THE OWNER'S MANUAL.
2. Do not allow children to operate machine; nor adults to operate it without proper instruction.
3. Clear work area of objects which might be picked up and thrown.
4. Disengage all clutches and shift into neutral before starting motor. Keep hands, feet and clothing away from power driven parts.
5. Do not carry passengers. Keep children and pets a safe distance away.
6. Never direct discharge of any material toward by-standers nor allow anyone near machine while in operation.
7. Disengage power to any attachment and stop motor before leaving operator position.
8. Take precautions when leaving machine unattended (to avoid accidental starting, rolling away, accidental dropping of any attachment, etc.)
9. Disengage power to any attachment whenever it is not in use or when traveling from one work area to another.
10. Stay alert for holes and other hidden hazards.
11. Know what is behind you before backing up.
12. Beware of steep slopes; reduce speed on all side slopes and sharp turns to prevent tipping or losing control.
13. Don't stop or start suddenly when going uphill or downhill.
14. Use extra care when pulling loads or using heavy equipment. (Refer to your owner's manual)
15. Watch out for traffic when near roadways.
16. Handle gasoline with care — it is highly flammable.
  - A. Use approved gasoline container.
  - B. Never add gasoline to running motor — fill tank out of doors and wipe up spilled gasoline.
  - C. Replace gasoline cap securely.
  - D. Open doors if motor is run in garage — exhaust gases are dangerous.
17. Keep machine in good operating condition and keep safety devices in place. Use guards as instructed in owner's manual.
18. Disengage power to any attachment and stop motor before making repairs or adjustments.
19. While operating the mower, if any foreign object is struck, stop the mower and inspect for damage. Do not restart or operate the mower until all damage has been repaired.

# KNOW YOUR TRACTOR





FIG. 1

## ASSEMBLY INSTRUCTIONS

1. Place battery to be filled on bench or workbench. Never activate battery in tractor. Remove vent plugs from all cells.
2. Fill each cell carefully using battery grade 1.250-1.265 specific gravity Sulfuric Acid to 3/8" above the top of the separators or to the split ring.
3. Allow battery to set for 20 minutes. Battery can then be installed, however, to have maximum capacity the battery should be placed on a charger after the 20 minutes setting period. Battery can be charged at maximum of 35 amperes until the specific gravity reading is 1.265-1.275.
4. The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225 remove battery and recharge.
5. The battery should be kept clean. Any deposits of acid should be neutralized with soda and water. Be careful not to get this solution in the cells. Coat the terminals with a thin coat of grease.
6. If the battery is not going to be used in the winter, remove the battery and store in a cool, dry place. Do not store directly on a concrete floor as this will drain the battery. Recharge whenever the specific gravity is less than 1.225.

### 725-130 BATTERY SPECIFICATIONS

<b>45 AMP.HRS. at 20 HRS. PLATES PER CELL 9 ASSEMBLY LEFT HAND WEIGHT WET 22 LBS. WEIGHT DRY 17 LBS.</b>	<b>ELECTROLYTE 2 QUARTS SPLASH PROOF VENTS TERMINALS REGULAR AUTOMOTIVE TYPE – ROUND – ONE LARGE AND ONE SMALL</b>	<b>SIZE 9 x 6-3/4 x 7-1/2</b> 
--	--	--

#### WARNING

SINCE BATTERY ACID IS CORROSIVE TO METALS, DO NOT POUR INTO ANY SINK OR DRAIN. RINSE EMPTY ELECTROLYTE CONTAINERS AND MUTILATE BEFORE DISCARDING. IF ACID IS ACCIDENTALLY SPILLED ON BATTERY DURING FILLING OR CHARGING, OR ON BENCH OR CLOTHING, ETC., FLUSH OFF WITH CLEAR WATER AND NEUTRALIZE WITH SODA OR AMMONIA SOLUTION.

#### INSTALLING THE BATTERY

Place the battery in the tractor with the negative terminal towards the front of the tractor. Before sliding the battery all the way in, attach the positive battery cable (red) to the positive terminal and attach the negative battery cable (black) to the negative terminal. Slide the battery into the proper position and use the hold down rods and cross rod with the washers and wing nuts to hold the battery in place. Screw wing nuts finger tight. Overtightening can crack the battery case. (see Fig. 2)

#### CHECK TIRE PRESSURE.

Use 10 to 12 pounds pressure for grass cutting. Use 15 to 20 pounds for field work.




FIG. 2

#### BEFORE STARTING

##### FILL FUEL TANK

Use clean, fresh "regular" grade gasoline. Fill tank completely.

DO NOT FILL GASOLINE TANK WHILE ENGINE IS RUNNING. Avoid spilling gasoline on a hot engine — this may cause an explosion and serious injury.

DO NOT MIX OIL WITH GASOLINE

##### OIL RECOMMENDATIONS

**WINTER**  
(Below 40° F.)  
Use SAE 5W-20

**SUMMER**  
(Above 40° F.)  
Use SAE 30

Any high quality detergent oil having the American Petroleum Institute classification "For Service MS" can be used in your Briggs & Stratton engine. Detergent oils keep the engine cleaner and retard the formation of gum and varnish deposits.

The above oil recommendations are the result of extensive testing. No special additives should be used.

##### FILL CRANKCASE WITH OIL




FIG. 3

Remove the oil filler plug. Place the engine level. Fill the crankcase to overflowing. POUR SLOWLY. CAPACITY 4 PINTS. Replace the filler plug.

# GENERAL INFORMATION

## ENGINE AND DRIVE TRAIN

Engine — 10 or 14 HP Synchro-Balanced Briggs & Stratton cast iron block with 12 volt electric starter.

Transaxle — Peerless with four forward speeds and reverse. Creeper gear — 3/4 MPH at full throttle. Fourth gear 6-1/2 MPH at full throttle. All speeds variable with throttle.

Clutch — Five and one half inch double faced disc clutch.

## ORIENTATION

Your tractor is right hand (R.H.) or left hand (L.H.) as you operate it. Direction of rotation is clockwise (C W) and counterclockwise (C C W) as observed from the operator's position, looking down. (Turning the steering wheel C W would turn the tractor to the right) C W and C C W on the vertical plane would be observed facing the R H side of the tractor.

## CLUTCH-BRAKE PEDAL

This pedal is operated with your left foot. Depress half way down to declutch, depress all the way down to declutch and brake, coming to a complete stop. Always depress the pedal when shifting gears. Release pedal slowly to engage clutch.

## PARKING BRAKE

The brake is located on the low L H side of the tractor. To operate, depress the clutch-brake pedal completely and lock it by turning the parking brake knob C W until it tightens. To release the brake, turn the knob C C W one complete revolution. (see Fig. 5)




FIG. 4

## GEAR SHIFT LEVER

The selection of the correct gear and throttle setting will be determined by the attachment being used. Generally, anything that uses the tractor engine as a power source should be run at full throttle with the ground speed determined by the gear selection.

A lock is provided to prevent accidentally engaging the creeper (1st gear) gear. (see Fig. 4)

## DASH PANEL CONTROLS




FIG. 5

## LIFT LEVER

The lift lever is used to change the height of the attachments such as the cutting deck, tiller and plow. To operate, depress the thumb button, move to the desired height and release the button.

The plow hitch operates off the lift lever and does not have to be disconnected when attaching the cutting deck or snow blade. (see Fig. 1)

## POWER TAKE OFF (P T O)

There are two PTOs on your tractor. One is located under the frame of the tractor and is to be used for the cutting attachment and rotary tiller. This PTO has a disengagement lever located on the RH side of the tractor. It is shown in the picture in the DIS-engaged position. It should be in this position whenever it is not in use. (see Fig. 6)

The second PTO is used to operate equipment attached to the front of the tractor such as the snow thrower. (see Fig. 1)

## IGNITION SWITCH

Turn key to the right (C W) to engage starting motor on engine. Remove key from switch when tractor is not in use. (see Fig. 5)

## THROTTLE CONTROL

Used to regulate engine speed. Move throttle control up to increase engine speed and down to slow down engine. (see Fig. 5)

## CHOKE

To start engine, pull all the way out. After engine starts, move choke in half way. After engine warms up, move choke in gradually until it is completely in. (see Fig. 5)

## LIGHTS

Pull switch button out to turn on head lights. (see Fig. 5)

## WHEELS

Front ..... 16 x 6.50 — 8" High Floation  
Rear ..... 23 x 8.50 — 12" High Floation  
Valve stems are to the inside to accommodate wheel weights for the rear wheels. 100 pound (total weight) wheel weights are available.

## HOOD

Hood pivoted at the front for easy access to engine and clutch. To open, release latches on each side of the hood. (see Fig. 1)

## STEERING ASSEMBLY

Segment and pinion with 2:1 ratio for easy steering. Automotive type adjustable tie rods for toe-in adjustment. Cast iron pivoted front end.

## WHEEL ADJUSTMENT

Each rear wheel can be adjusted out 2" on the axle. Details covered in the adjustment section of this manual. (see Fig. 10)

## TIRE PRESSURE: Front and Rear

Tire pressure for grass cutting is 10 to 12 pounds. For field operation or tilling increase pressure to 15 to 20 pounds.

## AMMETER

The ammeter registers the rate of battery charge or discharge. The ammeter should register on the plus (+) side when the engine is running in the "Fast" position until the battery is completely charged. With a fully charged battery or with the engine idling the ammeter will not show a charge. (see Fig. 5)

## SEAT—TWO PIECE ASSEMBLY (OPTIONAL ON 10 H.P.)

Fully padded for comfort. Back adjustable by loosening hand knob. Seat adjusts back and forward by loosening the large hex nut under the seat and sliding the seat back or forth.

# OPERATING INSTRUCTIONS

## STARTING YOUR ENGINE

To get the feel of your tractor, operate it in a large open space until you become familiar with the controls.

1. Be sure you have read the manual to acquaint yourself with the controls.
2. Fill engine with oil and gasoline as outlined on page 3 of this manual.
3. Open fuel shut-off valve located under the gasoline tank.
4. Place gear shift lever in neutral position.
5. Depress clutch-brake pedal and lock into disengaged position with the parking brake.
6. Pull choke out all the way.
7. Place throttle lever in 1/2 throttle position.
8. Turn ignition key (C W) to engage starter. When engine starts, move choke in half way. After engine warms up, move choke in gradually until completely in.

### CAUTION

Do NOT run starter for more than 30 seconds at a time. If engine does not start after several tries, place throttle control in "fast" position, wait several minutes and try again without moving the throttle lever from the "fast" position.

## STOPPING YOUR ENGINE

Turn ignition key to the left (C C W). Remove key from ignition when tractor is not in use to prevent accidental starting.

Remove spark plug wire from spark plug when tractor is not in use to prevent accidental starting.

## TO OPERATE THE TRACTOR

1. Move throttle control to 1/2 throttle position.
2. Place left foot on clutch-brake pedal and hold down while you release the parking brake.
3. Place the gear shift lever in second gear. (Use a low gear until you get the feel of your tractor.)
4. Slowly let out the clutch-brake pedal until it is completely released.

### NOTE

When operating attachments such as the cutting unit or tiller that uses the tractor engine as source of power, run the engine at near full or full throttle. Set your ground speed by changing transmission gears.

### CAUTION

Do not force the gear shift lever if the gears do not immediately mesh. Release the clutch-brake pedal and depress again until it shifts easily.

Do not shift while in motion.

Always release the clutch-brake pedal slowly.

## STOPPING YOUR TRACTOR

Disengage the transmission by depressing the clutch-brake pedal and shifting into neutral.

If you park the tractor, set the parking brake and leave the transmission in gear. Before starting the engine again, place gear shift lever in neutral.

## POWER TAKE OFF (PTO)

The PTO should be in the "OFF" position (Handle Down) when starting the engine and when attachments using the PTO are not on the tractor. If, while using the cutting unit or the rotary tiller, they become clogged and will not operate, shut off the engine AND THE PTO before clearing the attachment.

The PTO engagement lever should be engaged fast to prevent wear on the PTO belts.

The cutting unit and the rotary tiller can be raised or lowered while they are operating under full power. For example, the rotary tiller can be lifted from the ground with the left lever in order to turn the tractor around without shutting off the PTO.

# MAINTENANCE

## BELTS

PTO BELT REMOVAL — To remove the belt: (see Fig. 6)

1. Set the engagement lever in the ENGAGED position.
2. Remove the spring.
3. Remove the belt guard on the PTO by removing 2 bolts and lock-washers.
4. Remove hex bolts (Ref. No. 151) and lock washers (Ref. No. 239).
5. Remove hex nut (Ref. No. 191) and lock washer (Ref. No. 246) and hex bolt (Ref. No. 282).
6. Push the entire clutch back as far as it will go by hand and remove the belt between the yoke and clutch.
7. ALWAYS replace both belts at the same time.

### NOTE

If the lower belt guard is too far away from the PTO belts it will not "trap-out" the belt on the yoke and the belts will continue to rotate slowly. Adjust the belt guard for minimum clearance (not touching) when the PTO handle is in the engaged position.

## BOLT




FIG. 6

### TRANSMISSION BELT:

**Adjustment** — The tension of the belt is increased by **UNSCREWING** the leveler screw until you obtain a 1/2" deflection on the belt when you apply 10 pounds of force midway between the transmission pulley and the pulley. Lock leveler in place by tightening the lock nut.

**Removal** — Screw the leveler screw all the way in until the idler is loose and remove the belt. (see Fig. 8)




FIG. 8

### POWER TAKE OFF (PTO) (see Fig. 7)

**Adjustment** — If the PTO creeps when it is in the disengaged position the belt should be adjusted. To adjust:

1. Set the engagement lever in the **ENGAGED** position.
2. Remove the cotter-pin on the PTO adjusting rod.
3. Remove the rod from the bracket and unscrew it 3 complete turns and insert back into the bracket.
4. Replace the cotter-pin.




FIG. 7

### STARTER-GENERATOR BELT

If the starter-generator turns over and the engine does not turn over or there is a high pitched squeel when the starter-generator is turned on, it is an indication of a loose belt.

**Adjustment** — To tighten, loosen the bolt in the bracket slightly, loosen the bolt in the adjusting strap and swing the starter-generator away from the engine until the belt is tight. (Belt should deflect 1/4" when depressed with your thumb.) Tighten all bolts. (see Fig. 9)

**Removal** — Follow same procedure as above except when the bolts on the bracket and adjusting strap are loose, swing the starter-generator towards the engine until the old belt can be removed and replaced. Follow the above procedure for tightening the new belt. (see Fig. 9)




FIG. 9

### WHEEL TREAD ADJUSTMENT

The tread on the rear wheels is adjustable from 29" to 35" by loosening the hex nut on the rear hub and sliding the hub out. Do not extend the hub beyond the 3 inches. Tighten the hex nut. Both wheels should be in the same relative position on the axle. (see Fig. 10)




FIG. 10



## LIFT LEVER LOCKOUT

The lift lever can be locked out so it is free floating and the ratchet does not engage. This is done by depressing the thumb button on top of the lift lever and moving the lockout in the direction of the arrow. (see Fig. 11)




FIG. 11

## CLUTCH AND BRAKE ADJUSTMENT

The clutch and brake should always be adjusted at the same time. To adjust:

1. Loosen the elastic stop nut until the chain is slack.
2. Tighten the elastic stop nut until the SLACK is out of the chain and there is 1/32 free play between yoke and bearing when clutch is engaged. Bearing should be free to rotate with shaft.
3. Depress the clutch brake pedal all the way and check the distance between the pressure plate and the clutch disc.
4. The distance should be approximately 1/16 of an inch.




FIG. 12

**FINE BRAKE ADJUSTMENT** — Remove hair pin (C). Turn the castle nut (B) clockwise to tighten one quarter revolution and check brakes. Repeat as necessary to have proper braking power. Replace hair pin (C). (See Fig. 13).




FIG. 13

**PEDAL ADJUSTMENT** — To take up the adjustment on the brake linkage, tighten or loosen the hex nut (A) on brake linkage. (See Fig. 13).

## THREE POINT HITCH ASSEMBLY INSTRUCTIONS

### NOTE

Mowing unit must not be on tractor. If so remove mowing unit before assembly of hitch kit.

1. Assemble the lift pull rod assembly (Ref. No. 70) to lift handle assembly (Ref. No. 58) on the right hand side, with clevis pin (Ref. No. 220), flat washer (Ref. No. 264) and hairpin cotter (Ref. No. 199). Assemble the second lift pull rod assembly (Ref. No. 70) to lift arm assembly (Ref. No. 136) on the left hand side, with clevis pin (Ref. No. 220), flat washer (Ref. No. 264) and hairpin cotter (Ref. No. 199).
2. Thread adjustment clevis assembly (Ref. No. 138) on end of pull rod assembly (Ref. No. 70).
3. Move lift lever to full engaged position.
4. Assemble link clevis pins (Ref. No. 226) to frame with lockwashers (Ref. No. 287) and hex nuts (Ref. No. 94). (See Drawing on Page 20).
5. Assemble draft bar assembly—R.H. (Ref. No. 227) to frame & clevis pin (Ref. No. 226) with hairpin cotter (Ref. No. 199). Do the same on the left hand side.
6. Pull the lift pull rods (Ref. No. 70) to the rear of the tractor and line up holes in pull rod and draft bar assembly. Insert clevis pin (Ref. No. 222) and secure with flat washer (Ref. No. 264) and hairpin cotter (Ref. No. 199).
7. Place upper hitch bracket (Ref. No. 224) against rear frame section of tractor, secure in position with spring lockwasher (Ref. No. 285) and hex bolt (Ref. No. 286).
8. Place clevis screw assembly (Ref. No. 223) in upper hitch bracket (Ref. No. 224) secure with clevis pin (Ref. No. 225) and hairpin cotter (Ref. No. 199).
9. Thread on adjustment clevis ass'y. (Ref. No. 138).
10. Place draw bar assembly (Ref. No. 69) between draft bars and secure with hairpin cotter (Ref. No. 199).
11. Assemble hitch chain hooks (Ref. No. 289) to draft bar ass'y, (Ref. No. 227) & (Ref. No. 290). Secure with hex nuts (Ref. No. 288).

## TIE ROD ADJUSTMENT (Toe-In)

The caster (forward slant of the kingpin) and the camber (tilt of the wheels out at the top) requires no adjustment. Automotive steering principles have been used to determine the caster and camber on the tractor.

The front wheels should be toe-in  $1/8''$ . To adjust the toe-in, loosen the hex jam nut, remove the elastic locknut, lift the tie rod end out of the hole in the steering arm and screw the tie rod end in or out to make your adjustment. The distance "B" must be less than "A" by  $1/8''$ . (see Figs. 15 & 16)




FIG. 15

## TIE-ROD END




FIG. 16

## BATTERY CARE

**Battery Failure** — Many times new batteries are returned for charging within a few days or a week after sale. Before returning the battery to the dealer who sold you the tractor, make these following checks.

1. Was the battery fully charged when installed? The dry-pack battery should have been placed on a charger and the specific gravity of the battery should read 1.265 to 1.275 before it was installed in the tractor.
2. Were the battery terminals clean, greased and properly tightened when the battery was installed?
3. Batteries are usually involved in ANY starting failure, however, insufficient hours of driving, worn cables, trouble in the electrical system, corroded connections, slipping drive belt can cause a battery to become discharged without the battery being a fault.

## SERVICING YOUR BATTERY

It is all right to use drinking water in your battery, excluding mineral water.

Adding water to a battery cell will lower the specific gravity of the electrolyte. Water should not be added unless the tractor is going to be run immediately during freezing weather.

Maintain electrolyte level in the battery to the level indicated on the top of the battery.

Keep the terminals clean and coated with grease.

## BATTERY STORAGE

If your tractor is to be stored during an off-season, the battery should be removed from the tractor, placed on a charger until the specific gravity reads 1.265 to 1.275 and stored at approximately 72°F. Batteries should not be placed directly on cement as this will drain the battery. Recharge to bring the specific gravity to normal before placing it in the tractor after storage.

## ENGINE REMOVAL

If the engine is removed from the tractor the following steps should be followed for the removal and installation of the engine.


## REMOVAL

1. Follow the steps to remove the Power Take Off belts shown in Fig. 6.
2. Remove the four engine bolts holding the engine to the frame of the tractor.
3. Remove the hood brace from the front grille to the dash board.
4. Remove the three wires to the starter-generator (red wire to the L.H. terminal and small black wire and large black wire to the R.H. terminal).
5. Shut off the gas valve and disconnect the gas hose.
6. Disconnect the throttle and choke wires to the engine.
7. Lift out the engine.

## INSTALLATION

1. Set the engine in position and tighten the four engine bolts finger tight.
2. Attach the Power Take Off belts. (see Fig. 6)
3. Attach hood brace and wiring.
4. Attach choke and throttle wires to engine.
5. Attach gas line and open valve.
6. Tighten engine bolts.

## BRAKE ASSEMBLY



**Fig. 17**

## CLUTCH REPAIR (Refer to Page 11)

Any repair of the Clutch, Throw Out Assembly, or Right Angle Drive requires removal of the complete assembly from the tractor.

1. Loosen the screw on the Belt Idler Bracket Assembly. Remove the Belt. (Refer to Page 11)
2. Remove the Elastic Stop Nut and Washer on the Clutch Adjustment Rod.
3. Remove the Elastic Stop Nut and Washer on the Clutch Yoke.
4. Four Cap Screws hold the Right Angle Drive Bracket to the Frame. Remove these four screws.
5. Move back the Right Angle Drive and Clutch approximately  $\frac{1}{4}$  inch. Remove entire Assembly from the Tractor.
6. Put Clutch Unit and Right Angle Drive in a vise.
7. Place "C" Clamps over Outer Disc Assembly and bottom of Right Angle Drive mounting plate as shown in Fig. 18.
8. Drive out Spirol Pin, and slowly release "C" Clamps to relieve spring pressure.
9. Removal of the second Spirol Pin will free the other parts for inspection or replacement.




FIG. 18

## CLUTCH INSTALLATION

1. To reassemble the Clutch Assembly, reverse preceding instructions.
2. Mount Clutch Assembly in Tractor. Assemble the Clutch Yoke to the Pivot Bracket and fasten with Shoulder Bolt, Washer and Elastic Stop Nut. Tighten Elastic Stop Nut and then back off one half turn. Clutch Yoke should then move freely.
3. When fastening Right Angle Drive Bracket to Frame, position to obtain correct Spring clearance on Clutch Yoke. Spring should be centrally located in Clutch Yoke, free from all contact with the formed edge. It should remain this way in either Engaged or Disengaged position and with the Engine running.
4. Install the Belt and unscrew the Leveler Screw until you obtain a  $\frac{1}{2}$ " deflection on the Belt when you apply a 10 pound force midway between the Transaxle Pulley and the Right Angle Drive Pulley.
5. Adjust the Clutch and Brake as shown on Page 9 of this manual




FIG. 19

## LUBRICATION

Your tractor has been engineered to give you years of trouble-free service, however, by following these simple lubrication procedures, you can greatly extend the life of your tractor.

Ref. No.	LUBRICATION CHART (SEE FIG. 23-27)	25 Hours	50 Hours	Once a Season
1	Engine — Oil Recommendations. * Winter (Below 40°F) SAE 5W-20 Summer (Above 40°F) SAE 30	x		
2	Transaxle — Lubricated with 4 pints of SAE E.P. 90 oil. Refill if below upper plug level.		x	
3	Right Angle Drive — Lubricated with 6 oz. of E.P.G. Lithium Grease.			#
GREASE FITTINGS ( ) No. of Fittings Use automotive multi-purpose grease				
4	Pivot Bolt (1)	x		
5	Wheel Bearings (2)	x		
6	King Pins (2)	x		
7	Deck Pivot Bar (2)	x		
8	Steering Arm (1)	x		
9	Clutch (1) +	x		
10	Power Take Off (1)	x		
APPLY GREASE Use automotive multi-purpose grease				
11	Steering and Segment Gears			x
12	Power Take Off Idler Brkt.			x
13	Power Take Off Lever			x
OIL THESE PARTS Use Engine Oil				
14	Lift Lever	x		
15	Chain (on Clutch not shown)	x		
16	Plow Hitch	x		
17	Clutch Pivot Point	x		

Oil all other pivot points once a season.

\* Change oil after the first five hours of operation and every 25 hours thereafter. Use any high quality detergent oil.

+ To lubricate the clutch, rotate the clutch housing until you can see the grease fitting. Depress the clutch-brake pedal and set the parking brake.


Lubricate with 3 squirts (1/2 oz.) of grease with the grease gun provided with your tractor or the equivalent. DO NOT OVER-LUBRICATE. Too much grease will go beyond the bearing and on to the face of the clutch.

# Check lubricant level only if the drive train is removed from the tractor for repair or if grease leaks from the right angle drive. Remove the four screws holding the cover and fill with E.P.G. Lithium grease so it just covers the spline shaft (6 oz.) See figures 17 and 20.

The following parts are sealed and require no further lubrication:


Idler Bearings:  
Power Take Off  
Transaxle Belt

Tie Rod and Drag Link Ends



CLUTCH

FIG. 20



BOTTOM  
OF  
TRACTOR

FIG. 21




FIG. 22




FIG. 23

ILLUSTRATED PARTS FOR 141-760, 141-860 AND 141-960 TRACTOR  
PARTS LIST ON PAGE 23




FIG. 24



FIG. 25 is a detailed perspective view of a mechanical assembly, likely a sewing machine, showing various components and their interconnections. The assembly includes a large flywheel, a motor unit, and a complex linkage system. Numerous parts are labeled with reference numerals.

- 17 -

[illegible]

— 18 —

# LIFT LEVER & PLOW HITCH

**NOTE:** Three Point Hitch Comes on 14 H.P. Tractor. It is optional on the 10 and 12 H.P. Tractors.




FIG. 27

# POWER TAKE OFF




FIG. 28

# CLUTCH





FIG. 29

## DIAGRAM FOR ELECTRICAL SYSTEM



## PARTS LIST FOR ELECTRICAL SYSTEM

Ref. No.		DESCRIPTION
1	394-9516	Head Lamp Bezel
2	721-112	Gasket
3	725-222	Head Lamp
4	725-204	13"—Head Lamp Ground Wire 18 Ga. Black
5	725-120	Voltage Regulator
6	725-144	Starter—Generator
7	711-278	Battery Hold Down Rod
	712-113	Wing Nut
	736-264	Flat Washer
	711-284	Battery Hold Down Stud
8	725-130	Battery—12 Volt
9	725-139	16-3/4"—Battery to Ground Wire 6 Ga. Red
10	725-138	20"—Wire from battery to starter— sw. to ammeter 18 Ga. Red
11	725-199	Starter Switch—Key operated
12	725-201	Starter Key
13	725-119	Ammeter
14	725-202	Head Lamp Switch
15	725-205	Wire Harness
16	710-346	Hex Head Cap Screw 1/4-20 x 1-1/2" lg.
	736-329	Spring Lockwasher 1/4" Screw*
	712-287	Hex Nut 1/4-20 Thc.

\*Common Hardware, purchase locally.

# PARTS LIST FOR 141-760, 860 AND 960 TRACTORS

Ref. No.	Part Number	DESCRIPTION	Ref. No.	Part Number	DESCRIPTION
1.	438-10384	Frame - Rail Assembly - L. H.	65.	736-185	Flat Washer*
2.	438-9402	Frame - Rail Assembly - R. H.	66.	712-107	Hex Locknut 1/4-20 Thd.*
3.	438-9511	Frame - Front Assembly	68.	713-148	Chain
4.	438-9403	Gear Box Mount Assembly	69.	438-10996	Draw Bar Ass'y.
5.	438-9406	Frame - Plate Assembly - Rear	70.	438-10923	Lift Pull Rod Ass'y.
6.	438-9410	Gear Box Mounting Bracket Assembly	71.	438-10457	Front Hub Assembly
7.	438-9412	Gas Tank & Bat. Mount. Bracket Assembly	72.	741-141	Ball Bearing
8.	310-10453	Clutch Yoke	73.	737-108	Grease Fitting
9.	901-10458	Clutch Assy. w/Rt. Angle Drive	75.	438-9583	Idler Bracket Assembly Complete
10.	732-207	Yoke Return Spring	76.	438-9446	Left Half Bracket Assembly
11.	438-10385	Transaxle Mounting Brk. Assy.	77.	438-10116	Right Half Bracket
12.	732-202	Brake Tension Spring	79.	710-307	Leveler Screw
13.	711-432	Brake Ferrule	80.	438-10450	Clutch Yoke Pivot Bracket Assy.
14.	711-292	Brake Rod	81.	438-9580	Center Console Assembly
15.	310-10443	Disc Assembly - Clutch	82.	312-9522	Seat Assembly 10 & 12 H.P. Only
16.	438-10463	Spring Retainer		757-203	Seat Assembly 14 H.P. Only
17.	310-9498	Bearing Retaining Ring	83.	312-9572	Seat Back Assembly 10 & 12 H.P. Only
18.	710-473	Truss Hd. Machine Screw #10-24 x 1/2 lg.*	84.	312-9569	Seat Slide Plate Assembly 10 & 12 H.P. Only
19.	736-147	External Lockwasher #10 Screw*	85.	438-9582	Foot Pad Assembly - R. H.
20.	717-160	Drive Disc - Clutch	86.	438-9480	Second Gear Stop
21.	723-231	Caliper Disc Brake Assembly	87.	438-9493	Rear Fender
22.	05-1862-0000	Pin Cotter	88.	438-9516	Bezel - Head Lamp
23.	02-1011-0000	Nut, Castle	89.	312-9525	Hood
24.	310-10444	Disc Assembly - Clutch	90.	438-9438	PTO Spring Bracket
25.	03-1030-0000	Washer, Thrust 5/16"	91.	438-9433	Index Bracket
26.	736-112	Belleville Washer	92.	438-9408	Side Plate R. H.
27.	438-9517	Steering Tube Seg. Assembly	93.	438-9477	Idler Crank
28.	748-157	Steering Tube Bushing	94.	712-923	Hex Center Locknut 5/8-18 Thd.*
29.	310-9535	Steering Rod	95.	711-447	Spring Guide - Clutch
30.	719-121	Pinion Gear	96.	438-9538	Hood Stop
31.	719-122	Gear Segment	97.	438-9575	Hood Catch
32.	310-9563	Gear Segment Shaft	98.	438-9576	Grille Brace
33.	715-101	Roll Pin 1/4 x 1-1/2 lg.	99.	438-9479	Lift Bar
34.	737-479	Grease Fitting	100.	438-9476	PTO Belt Trapout
35.	710-349	Square Hd. Set Screw 5/16-18 x 3/4 lg.*	101.	438-10489	Clutch Idler Bracket Assembly
36.	901-9578	PTO Shaft Assembly - Complete	102.	438-9457	Pivot Bar Assembly
37.	719-134	PTO Shaft Housing	103.	348-335	Pivot Bolt
38.	711-298	PTO Shaft	104.	712-205	Elastic Stop Nut 3/4-10 Thd.
39.	719-130	PTO Drive Pulley	105.	719-123	Transaxle Drive Sheave
40.	741-123	Needle Bearings 3/4 I.D. x 1.187 O.D.	106.	901-10467	PTO Drive and Adapter Assembly
41.	741-151	Thrust Race	107.	719-133	Front Axle Support
41.	741-150	Thrust Bearing	108.	711-282	Hitch Pin
42.	711-139	Collar	109.	711-454	Tie Rod
43.	716-110	Snap Ring	110.	711-455	Drag Link
44.	714-314	Key - Hi Pro #606	111.	723-156	Tie Rod Ends
45.	737-109	Grease Fitting 1/4-28 x 11/16 Thd.	112.	723-179	Drag Link Ends
46.	710-356	Sq. Hd. Cut. Pt. Set Screw 5/16-18 x 1/2 lg.*	113.	723-182	Gas Tank w/straps
47.	438-9496	PTO Mounting Bracket	114.	723-155	Gas Gauge
48.	710-289	Hex Head Screw 1/4-20 x 1/2 lg.	115.	723-152	Gas Hose 1/2" O.D. x 1/4" I.D. x 1-1/2" lg.
49.	736-329	Spring Lockwasher 1/4 Screw*	116.	723-154	Gas Filter
50.	754-123	PTO Belt 33" lg.†	117.	723-157	Hose Clamps 1/2" O.D.
51.	438-9494	PTO Belt Guard Assembly	118.	723-159	Gas Valve
52.	310-9439	PTO Handle	119.	723-153	Gas Hose 1/2" O.D. x 1/4" I.D. x 10-1/2" lg.
53.	438-10688	PTO Handle Shaft Assembly	120.	723-185	Steering Wheel
54.	402-10690	Handle Support Assembly	121.	723-186	Hood Latch
55.	438-9422	Axle Assembly - Front - R. H.	122.	723-188	Steering Wheel Cap
56.	438-9423	Axle Assembly - Front L. H.	123.	723-189	Seat Back Spring 10 & 12 H.P. Only
57.	901-9466	Lift Handle Assembly Complete	124.	723-190	Seat Cover 10 & 12 H.P. Only
58.	438-9467	Lift Handle Assembly	125.	723-191	Seat Back Rest Cover 10 & 12 H.P. Only
59.	438-9470	Handle Spacer Tube	126.	723-181	Seat Spring
60.	305-8818	Handle Grip	127.	719-139	Grille
61.	726-110	Push Cap	128.	719-137	Front Sheave
62.	732-156	Compression Spring	129.	719-140	Gear Box Sheave
63.	438-9448	Lift Handle Lockout	130.		Transaxle w/gear Shift Lever
64.	710-252	Hex Hd. Cap Screw 1/4-20 x 3/4 lg.*			

# **PARTS LIST FOR TRACTOR (Continued)**

Ref. No.	Part Number	DESCRIPTION	Ref. No.	Part Number	DESCRIPTION
131.		Right Angle Gear Box	196.	713-136	Clutch Bracket Chain
132.	715-107	Spirol Pin 5/16-1-3/8 Ig.*	197.	713-116	Master Link
133.	736-182	Wave Washer	198.	719-158	PTO and Drive Adapter
134.	748-386	Axle Collar	199.	714-117	Hair Pin Cotter
135.	710-346	Oval Hd. Screw 1/4-20 x 1-1/2 Ig.*	200.	714-118	Square Key 1/4 x 1-1/2 Ig.*
136.	438-10716	Lift Arm Ass'y.	201.	714-119	Square Key 1/4 x 3/4 Ig.*
137.	710-356	Sq. Hd. Set Screw 5/16-18 x 1/2 Ig.*	202.	714-120	Square Key 1/4 x 3 Ig.*
138.	438-10991	Adjustment Clevis Ass'y.	203.	714-121	Cotter-Pin 5/32 Dia. x 1 Ig.*
139.	438-9405	Frame - Rear	204.	714-474	Cotter - Pin 1/8 Dia. x 3/4 Ig.*
140.	732-145	Spring	205.	715-107	Spirol Pin 5/16 x 1-3/8 Heavy Duty*
141.	711-293	PTO Clutch Rod	206.	715-113	Spirol Pin 5/16 x 2-1/2 Heavy Duty*
142.	722-117	Parking Brake Knob 10 & 12 H.P. Only	207.	715-101	Spirol Pin 1/4 x 2-1/2
143.	732-179	Compression Spring 10 & 12 H.P. Only	208.	716-101	Snap Ring Truarc #5100-75
144.	710-106	Hex Hd. Cap Screw 1/4-20 x 1-1/2 Ig.*	209.	15-1070-1069	Pad, Friction
145.	18-1759-0000	Cam (Lever)		15-1070-1049	Pad, Friction
146.	710-166	Truss Hd. Machine Screw 1/4-20 x 1-1/8 Ig.*	210.	716-111	Snap Ring Truarc #5100-87
147.	710-182	Hex Hd. Cap Screw 1/2-13 x 3 Ig.*	211.	723-236	Brake Disc Assembly
148.	710-198	Sems Hex Hd. Cap Screw 5/16-18 x 3/4 Ig.*	212.	722-116	Gear Shift Knob
149.	710-211	Sems Hex Hd. Cap Screw 1/4-20 x 3/4 Ig.*	213.	722-118	Throttle Control Knob
150.	710-216	Hex Head Cap Screw 3/8-16 x 3/4 Ig.*	214.	736-214	Flat Washer
151.	710-253	Hex Head Cap Screw 3/8-16 x 1 Ig.*	215.	723-183	Serrated Plate
152.	710-258	Hex Head Cap Screw 1/4-20 x 5/8 Ig.*	216.	725-119	Ammeter
153.	715-121	Spirol Pin 1/4 x 2" Ig. Heavy Duty	217.	725-129	Ignition Switch
154.	710-322	Sems Hex Hd. Cap Screw 5/16-18 x 1 Ig.*	218.	725-130	Battery - 12 volt
155.	710-334	Shoulder Screw 3/8-16 x .625 Dia.	219.	725-131	Light Switch
156.	710-336	Wheel Lug Bolts 7/16-20 x 1-3/16 Ig.*	220.	711-309	Clevis Pin 5/8 Dia. x 1-1/16" Ig.
157.	710-342	Hex Hd. Cap Screw 3/8-16 x 1-1/4 Ig.*	221.	725-157	Cable Ties (Not Shown)
158.	710-344	Hex Hd. Cap Screw 3/8-16 x 1-1/2 Ig.*	222.	711-225	Clevis Pin 5/8 Dia.
159.	710-347	Hex Hd. Cap Screw 3/8-16 x 1-3/4 Ig.*	223.	438-10994	Clevis Screw Ass'y.
160.	710-348	Hex Hd. Cap Screw 7/16-20 x 3/4 Ig.*	224.	438-10993	Upper Hitch Bracket
161.	710-350	Counter Sunk Flat Hd. Screw 1/4-20 x 1 Ig.*	225.	711-174	Clevis Pin 5/8 Dia.
162.	710-351	Phil. Hd. Screw #10-Type Z - 1/2 Ig.*	226.	711-497	Link Clevis Pin
163.	710-355	Rd. Hd. Screw 1/4-20 x 1-1/4 Ig.*	227.	438-10986	Draft Bar Ass'y.—R.H.
164.	710-360	Carriage Bolt, 1/2-13 x 1-3/4 Ig.* 10 & 12 H.P. Only	228.	726-119	Button
165.	06-1029-0000	Spring, Compression	229.	727-143	Grease Gun
166.	710-473	Truss Hd. Mach. Screw #10-24 x 1/2 Ig.*	230.	728-111	Pop Rivet SD 44 B 5
167.	710-937	Hex Hd. Cap Screw 3/8-16 x 2-1/2 Ig.*	231.	728-113	Pop Rivet SD 64 B 3
168.	711-225	Clevis Pin	232.	732-155	Extension Spring
169.	711-278	Battery Hold Down Rod	233.	503-9262	Wheel Assembly - Complete **
170.	711-280	Brake Spacer Tube		312-9262	Wheel Rim
171.	711-284	Battery Hold Down Stud		734-275	Tire - Tubeless 16 x 6.50-8
172.	711-288	Ferrule	234.	734-262	Wheel Assembly-Complete** 10 H.P. Only
173.	711-289	Clutch Stud		734-320	Wheel Assembly-Complete (12 & 14 H.P.)
174.	711-292	Brake Rod		734-279	Wheel Rim
175.	756-127	Idler PTO		734-278	Tire - Tubeless 23 x 8.50-12
176.	711-308	Clevis Pin		734-322	Tire-Tubeless 23 x 9.50-12 (12 & 14 H.P.)
177.	711-309	Clevis Pin	235.	03-1031-0000	Disc, Back-Up
178.	711-310	Clevis Pin	236.	710-442	Hex Hd. Cap Screw 5/16-18 x 1-1/2 Ig.*
179.	711-313	Sleeve 10 & 12 H.P. Only	237.	736-133	Flat Washer*
180.	732-205	Clutch Spring	238.	736-147	External Lockwasher #10 Screw*
181.	05-1033-0000	Pin, Push	239.	711-444	Spring Collar - Clutch
182.	712-113	Wing Nut 1/4-20 Thd.*	240.	736-163	Flat Washer*
183.	712-116	Elastic Stop Nut 3/8-24 Thd.*	241.	736-148	External Lockwasher 3/8 Screw*
184.	712-193	Lug Nut 3/8-24 Thd.	242.	736-171	Spring Lockwasher 7/16 Screw*
185.	712-200	Elastic Stop Nut 1/2-20 Thd.*	243.	736-180	Flat Washer*
186.	712-204	Elastic Stop Nut 1/2-13 Thd.*	244.	736-181	Flat Washer*
187.	712-206	Hex Nut 1/2-13 Thd.* 10 & 12 H.P. Only	245.	736-264	Flat Washer 5/16 SAE*
188.	12-1984-0000	Casting, Cam Side	246.	736-300	Flat Washer*
189.	712-287	Hex Nut 1/4-20 Thd.*	247.	736-466	Flat Washer*
190.	712-425	Square Nut #10-24 Thd.*	248.	712-429	Elastic Stop Nut 5/16-18*
191.	712-430	Elastic Stop Nut 3/8-16 Thd.*	249.	736-860	Flat Washer*
192.	712-492	Square Nut 1/4-20 Thd.*	250.	736-921	Spring Lockwasher 1/2 Screw* 10 & 12 H.P. Only
193.	712-711	Hex Jam Nut 3/8-24 Thd.*	251.	737-111	Muffler Nipple 1" Dia. x 6" Ig.* ‡
194.	712-798	Hex Nut 3/8-16 Thd.*	252.	737-112	Gas Tank Nipple 3/8" Dia.*
195.	712-922	Hex Nut 1/2-20 Thd.*	253.	746-129	Choke Control
			254.	746-130	Throttle Control
			255.	310-9420-1	Clutch - Brake Pedal Assembly



## PARTS LIST FOR TRACTOR (Continued)

Ref. No.	Part Number	DESCRIPTION	Ref. No.	Part Number	DESCRIPTION
256.	438-10925	Clutch Brake Crank Assembly	274.	719-136	Rear Wheel Hub
257.	438-9431	Clutch Shaft Bracket Assembly	275.	754-124	Belt - Transaxle Drive 57-3/8 lg. (Gates 9224-2701)
258.	711-318	Sleeve	276.	725-128	Key
259.	310-9437	Brake Link	277.	438-10551	Gear Box Mounting Washer
260.	714-117	Hair Pin Cotter*	278.	438-9591	Gear Box Mounting Plate
261.	312-9531	Heat Shield Assembly	279.	732-204	Clutch Helper
262.	312-9529	Heat Shield Mounting Bracket Assembly	280.	310-10477	Bearing Assembly - Clutch
263.	438-9581	Foot Pad Assembly L. H.	281.	715-125	Spirol Pin 3/8 x 2" lg. Heavy Duty
264.	310-7387	Flat Washer 10 & 12 H.P. Only	282.	12-1536-0001	Casting, Carrier Side
265.	438-9409	Side Plate L. H.	283.	710-340	Shoulder Bolt 1/2" dia. x 3/4" lg.
266.	741-140	Ball Bearing	284.	754-139	Starter Generator "V"-Belt (Special)
267.	438-9445	Parking Brake Link	285.	736-217	Spring Lockwasher 3/8 Scr. Heavy Duty*
268.	312-9526	Generator Bracket	286.	710-253	Hex Hd. Cap Scr. 3/8-16 x 1-11/31*
269.	312-9527	Generator Pivot Bracket	287.	736-158	Spring Lockwasher*
270.	310-9528	Bezel - Instrument Panel	288.	712-342	Hex Jam Nut 3/8-16 Thd.*
271.	312-9534	Heat Shield Angle Bracket	289.	310-10988	Hitch Chain Hook w/3/8 Thd.
272.	305-9584	Instrument Panel	290.	438-10985	Draft Bar Ass'y.—L.H.
273.	438-9443	Parking Brake Bracket Assembly			

\*\* When ordering service parts include all the information on the side wall of the tire such as the size and brand name.

\* For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

+ Power Take Off belts are matched. Always order in pairs.

‡ Not shown. Nipple between engine and muffler.

# RIGHT ANGLE DRIVE FOR TRACTOR

PEERLESS  
RA-208-P91

**NOTE:** No Peerless, Tecumseh parts orders will be accepted by the mower manufacturer.

All parts **MUST** be ordered through your local authorized Tecumseh service dealer.

Find Us Fast  
In The  
Yellow Pages

## PEERLESS MODEL

Parts and service available through all authorized Tecumseh, Lauson Power Products Service Dealers. Check the "Yellow Pages" of your telephone directory under "Engines—Gasoline."




FIG. 31


## RIGHT ANGLE DRIVE MODEL NO. (PEERLESS RA-208-P91)

REF. NO.	PART NUMBER	DESCRIPTION
1	794077	Head Assy. Right hand (Incl. Nos. 2 thru 15)
2	770026	Housing, Right angle drive
3	778046	Gear, Miter
4	776116	Shaft, Input pinion
5	776060A	Shaft, Output
6	772034	Cover, Right hand
7	788028	Gasket, Cover
8	780034	Bearing, Ball
9	780024	Bearing, Ball
10	788019	Ring, Snap
11	788018	Ring, Snap
12	788029	Seal, Oil
13	788030	Gasket, Cap
14	792025	Screw, Rd. hd. self tap, 10-24 x 1/2
15	786029	Cap & Seal Assy., Retainer (Incl. Nos. 16 & 17)
16	788031	Seal, Oil
17	792026	Screw, Hex hd. 1/4-20 x 7/8

# TRANSAXLE PEERLESS 2315A

NOTE: No Peerless, Tecumseh parts orders will be accepted by the mower manufacturer.

All parts MUST be ordered through your local authorized Tecumseh service dealer.



Find Us Fast  
In The  
Yellow Pages

## PEERLESS MODEL

Parts and service available through all authorized Tecumseh, Lauson Power Products Service Dealers. Check the "Yellow Pages" of your telephone directory under "Engines—Gasoline."

# **TRANSAXLE MODEL NO. (PEERLESS 2315-A)**

Ref. No.	Part No.	DESCRIPTION	Ref. No.	Part No.	DESCRIPTION
1	784151	Lever & Housing Assy., Shift (Incl. Nos. 2 thru 7)	39	776015A	Shaft, Input
2	792016	Ring, Snap	40	778024	Spur Gear, Input shaft
3	792001	Ring, Quad	41	780052	Washer, Thrust
4	792002	Pin, Roll	42	788021	Seal & Retainer Assy., Oil (Incl. No. 45)
5	784093	Housing, Shift lever	43	778036	Gear, Output
6	784094	Keeper, Shift lever	44	776028	Pinion, Output
7	784152	Lever, Shift	45	788008	Seal, Oil
8	784054	Rod Assy., Shift (Incl. Nos. 9 thru 12 & 24)	46	782024	Housing, Axle
9	792003	Spring	47	772016A	Cover Assy., Transaxle (Incl. Nos. 54, 55, 57, 59 & 63)
10	792004	Ball, Steel	48	770012	Case Assy., Transaxle (Incl. Nos. 54, 55, 57 & 63)
11	784004	Fork, Shifter	49	792007	Screw, Socket hd. cap, 1/4-20 x 3/4
12	784055	Rod, Shifter (3rd & 4th)	50	786026	Pin, Dowel
13	784056	Rod Assy., Shift (Incl. Nos. 9, 10, 11 & 14)	51	792028	Screw, Hex hd. 5/16-18 x 7/8
14	784057	Rod, Shifter (low)	52	792019	Plug, Magnetic drain
15	774124	Axle	53	792029	Lockwasher, Split 5/16"
16	780042	Washer, Thrust	54	780049	Bearing, Needle
17	792005	Screw, Hex hd. cap, 1/4-20 x 2-1/2	55	780022	Bearing, Needle
18	792006	Lockwasher, 1/4	56	780024	Bearing, Ball
19	778033A	Gear, Ring	57	780047	Bearing, Needle
20	786019	Pin, Drive	58	780050	Bearing, Ball
21	786027	Block, Drive	59	780046	Bearing, Needle
22	778094	Pinion, Bevel	60	788025	Seal, Oil
23	776029A	Shaft & Gear, Brake	61	780001	Washer
24	792017	Ring, Snap	62	776031	Shaft & Pinion
25	776026	Shaft & Bearing Assy., Pinion (Incl. No. 26)	63	780048	Bearing, Needle
26	780018	Bearing	64	776030	Shaft, Reverse idler
27	778034	Gear Cluster Assy., (Incl. No. 28)	65	786025	Spacer, Reverse idler
28	780053	Bushing	66	778016	Idler, Reverse
29	784074	Stop, Shifter	67	778038	Spur gear (22 teeth)
30	788023	Gasket, Case & Cover	68	780039	Bearing, Thrust
31	788022	Gasket, Shift lever housing	69	774072A	Carrier Assy., Differential (Incl. No. 71)
32	778019	Gear, Shifting (3rd & 4th)	70	774071A	Carrier Assy., Differential (Incl. No. 71)
33	778020	Gear, Shifting (1st, 2nd & Rev.)	71	780041	Bushing
34	778095	Gear, Bevel	72	788024	"O" Ring
35	778037	Gear, Idler	73	780007	Washer, Thrust
36	778035	Gear Cluster Assy., (Incl. No. 28)	74	780051	Washer, Thrust
37	786024	Spacer	75	792010	Plug, Pipe
38	792018	Ring, Snap	76	780075	Race, Thrust